## SERVICE AT A GLANCE MAINTENANCE INTERVALS



**Volvo Trucks. Driving Progress** 

For Volvo VNR Electric
Manufactured Year 2021 and Newer

These maintenance intervals are general recommendations. Please refer to the appropriate maintenance and lubrication manual for your specific vehicle as the authoritative source for all details of a proper and complete inspection and maintenance plan for your vehicle. Recommended intervals by Miles, Km or Hours whichever occurs first.

MAIN SERVICE  Electric Truck Main Service Annual BEV Inspection Service, including comprehensive inspection of Electric Batteries.  TRANSMISSION AND AXLES		STANDARD INTERVAL  12 months  STANDARD INTERVAL			
			RANSMISSIONS I-SHIFT		
			Volvo Two-Speed I-Shift		
Transmission Oil and Filter (Replace) Oil Quality: Volvo Transmission Oil 97319	Miles	125,000			
	Km	200,000			
	Time	24 months			
Axles					
Synthetic Rear Axle Oil (Replace)	Miles	250,000			
	Km	400,000			
	Time	40 months			
CHASSIS					
<b>NOTE:</b> Volvo cannot be responsible for problems caused by non-genuine filters that do not meet Volvo performance or durability requirements.		STANDARD INTERVAL			
Volvo Premium Chassis Lubrication	Miles	15,000			
	Km	24,000			
Power Steering Fluid and Filter (Replace)	Miles	150,000			
	Km	240,000			
	Time	12 months			
Air Dryer Coalescing Cartridge (Replace)	Miles	150,000			
	Km	240,000			
	Time				
COOLANT					
Volvo Premium Long-Life Coolant (Replace)	Miles	300,000			
	Km	480,000			
	Time	48 months			
MISCELLANEOUS					
Cabin Air Filter	Time	12 months			
Electric Air Compressor Filter, Oil, and Oil Separator					